

Manual, Assembly instruction: Brodit 855170

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press/Hook the angled edge on the lower part of the ProClip into the gap behind the frame surrounding the air vent.
2. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener.
3. Press downward on top of the ProClip so the angled edge goes all the way into the gap and the adhesive tape attaches. Pull out the gap opener.
4. The ProClip is in place.