

Manual, Assembly instruction: Brodit 855171

Angled mount



Please read the instructions and look at the pictures before installing the ProClip.

1. Open the glove compartment. Press the thin end of the enclosed gap opener into the gap between the upper inside of the glove compartment and the surrounding frame, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip.

2. Hook the upper angled edge of the ProClip around the top of the shelf edge above the glove compartment.

3. Flex the lower angled edge of the ProClip downward and insert into the gap next to the gap opener. Remove the gap opener.

4. The ProClip is in place.