

Manual, Assembly instruction: Brodit 855175

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Insert the angled lower edge of the ProClip into the gap on the lower inside of the air vent.
2. Flex the angled upper edge of the ProClip downward/forward so the angled edge goes into the gap in the upper inside of the air vent.
3. Press upward on the upper edge of the ProClip so the adhesive tape fastens properly and the angled edge goes all the way into the gap.
4. The ProClip is in place.