

Manual, Assembly instruction: Brodit 855176

Angled mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Insert the thin end of the enclosed Gap Opener (Spaltöffner) into the gap of the trim dividing the dash, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip.
2. Insert the lower edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).
3. Insert the angled upper edge of the ProClip into the gap on the lower inside of the air vent. Press until the edge goes all the way into the gap and the adhesive tape fastens properly.
4. The ProClip is in place.