

Manual, Assembly instruction: Brodit 855188

Center mount, Low

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed gap opener into the gap dividing the center console, to widen the gap. Remove the adhesive tape cover on the ProClip. Insert the angled upper edge of the ProClip into the gap next to the gap opener. Remove the gap opener.

2. Push the lower part of the ProClip forward so the angled lower edge hooks into the gap on the bottom side of the center console.

3. The ProClip is in place.

4. The ProClip is in place.