

Manual, Assembly instruction: Brodit 855189

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip. Note: This ProClip can be place on the right side of the dash as well.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled lower edge of the ProClip into the gap between the frame surrounding the air vent panel and the remainder of the control panel.

2. Insert the thin end of the enclosed Gap Opener (Spaltöffner) into the upper gap between the frame surrounding the air vent panel and the remainder of the control panel, to widen the gap. Insert the angled upper edge into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).

3. The ProClip is in place.

4. The ProClip is in place.