

Manual, Assembly instruction: Brodit 855195

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip upward/forward into the gap between the frame surrounding the air vent and the dashboard overhang.
2. Press the lower part of the ProClip forward so the angled edge goes into the gap between the panel surrounding the air vent and the dashboard.
3. Press forward/downward on the lower part of the ProClip so the angled edge goes all the way into the gap and the adhesive tape attaches.
4. The ProClips is in place. This ProClip can also be installed on the right air vent.