

Manual, Assembly instruction: Brodit 855196

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard overhang, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip upward into the gap next to the gap opener. Pull out the gap opener.
2. Press the lower part of the ProClip upward/forward and hook the angled edge into the gap between the frame surrounding the air vent and the frame surrounding the control panel.
3. This ProClip can be placed anywhere within the width of the air vent.
4. The ProClip is in place.