

Manual, Assembly instruction: Brodit 855198

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Insert the angled left edge of the ProClip into the gap between the panel surrounding the speedometer/gauges and the padded part of the dash.

2. Push the ProClip rightward/forward so the notch on the inner right side of the ProClip clip into place around the air vent frame edge.

3. The ProClip is in place.

4. The ProClip is in place.