

Manual, Assembly instruction: Brodit 855200

Center mount Some 2016 Prius use the old dash. Please compare the pictures to match.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip. This ProClip can be placed on both the left and right air vent.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the angled Gap Opener (Spaltöffner) into the gap between the lower side of the frame surrounding the air vent and the air vent itself, to widen the gap. Remove the adhesive tape cover on the ProClip. Starting with the left side, insert the angled lower edge of the ProClip into the gap next to the Gap Opener (Spaltöffner).

2. Pull the ProClip slightly downward so the whole angled lower edge goes into the gap. Remove the Gap Opener (Spaltöffner).

3. Flex the upper edge of the ProClip downward so the upper edge can attach to the upper inside of the air vent. Press the upper edge upward so the adhesive tape fastens properly.

4. The ProClip is in place.