

Manual, Assembly instruction: Brodit 855201

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip. This ProClip can be placed on either left or right air vent.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the air vent and the surrounding trim on the bottom side of the air vent, to widen the gap. Remove the adhesive tape covers on the ProClip.

2. Attach the top edge of the ProClip to the upper inside of the air vent wall.

3. Press the lower part of the ProClip upward, flexing it. Insert the angled lower edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).

4. The ProClip is in place.