

Manual, Assembly instruction: Brodit 855202

Center mount



Please read all of the instructions and look at the photos before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the upper angled edge of the ProClip into the gap on the upper inside of the air vent. Use the enclosed gap opener to widen the gap, if needed.
2. Press upward on the lower part of the ProClip, making the upper angled edge go all the way into the gap and allowing the lower part to go into the air vent.
3. Press the lower part of the ProClip inward/forward so the lower notched edge hooks around the lower edge of the air vent.
4. The ProClip is in place.