

## Manual, Assembly instruction: Brodit 855211

Angled mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the left part of the ProClip over the center console frame.

2. Press the thin end of the enclosed gap opener into the gap in the center console sidewall and carefully prize it slightly wider. Hold the gap opener in that position, in the same time press forward on the right side of the ProClip so the angled edge hooks into the gap above the gap opener. Pull out the gap opener.

3. The ProClip mount is in place.

4. The ProClip mount is in place.