

Manual, Assembly instruction: Brodit 855213

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed gap opener into the gap dividing the center console paneling, to widen the gap. Remove the adhesive tape covers on the ProClip.
2. Insert the lower angled edge of the ProClip into the gap next to the gap opener. Remove the gap opener.
3. Insert the angled upper edge of the ProClip into the gap between the frame surrounding the air vent and the remainder of the dash. Use the gap opener to widen the gap slightly.
4. The ProClip is in place.