

Manual, Assembly instruction: Brodit 855217

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the padded part of the dash and the surrounding panel frame, to widen the gap. Remove the adhesive tape cover on the ProClip.
2. Insert the top edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Make sure it goes all the way into the gap and hooks behind the padding.
3. Insert the angled lower edge of the ProClip into the gap between the climate control panel and the surrounding frame. Remove the Gap Opener (Spaltöffner).
4. The ProClip is in place.