

Manual, Assembly instruction: Brodit 855219

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the S-shaped edge on the left part of the ProClip into the gap between the frame surrounding the control panel and the dashboard. Press the right side of the ProClip forward so the left edge hooks behind the frame surrounding the control panel.

2. Pull the right part of the ProClip away from the center console and hook the angled edge into the gap in the center console side wall.

3. Press the right part of the ProClip toward the dashboard so the angled edge goes all the way into the gap and the adhesive tape attaches.

4. The ProClip is in place.