

## Manual, Assembly instruction: Brodit 855231

Angled mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before installing the ProClip.**

**1.** Insert the lower angled edge of the ProClip into the seam between the dash panel to the left of the glove compartment door and the curved panel above.

**2.** Push the upper part of the ProClip upward. Make sure the lower edge stays in the seam.

**3.** Hook the upper angled edge of the ProClip into the seam, between the curved dash panel above the glove compartment door and the padded upper part of the dash.

**4.** The ProClip is in place.