

Manual, Assembly instruction: Brodit 855237

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Open the glove compartment. Remove the adhesive tape cover on the ProClip. Slide the angled lower edge of the ProClip into the gap on the upper edge of the glove compartment.

2. Slide the ProClip sideways until it rests on the center console.

3. Pull the upper part of the ProClip upward and insert the angled upper edge into the gap on the lower inside of the air vent.

4. The ProClip is in place.