

Manual, Assembly instruction: Brodit 855238

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip. This ProClip consists of two parts: Part 1 - Mount Part 2 - Attaching plate

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled edge of Part 1 into the gap on the outer side of the center console.

2. Place Part 2 onto Part 1, make sure the holes align and that the thin end goes into the gap next to the center console side wall.

3. Attach Part 2 onto Part 1 using the enclosed screws.

4. The ProClip is in place.