

Manual, Assembly instruction: Brodit 855239

Center mount



Please read the instructions and look at the pictures before installing the ProClip.

1. Insert one of the enclosed gap openers into the gap between the frame surrounding the information display and the remainder of the center console, to widen the gap. Insert the grooved lower edge of the ProClip into the gap next to the gap opener. Make sure it goes all the way in. Remove the gap opener.
2. Insert both gap openers into the gap by the lower edge of the air vent, to widen the gap.
3. Insert the angled upper edge of the ProClip into the gap between the gap openers. Remove the gap openers.
4. The ProClip is in place.