

Manual, Assembly instruction: Brodit 855241

Angled mount



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the glove box button and the right center console panel, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip.

2. Press the angled left edge of the ProClip into the gap below the gap opener. Remove the gap opener.

3. Press the thin end of the gap opener into the gap between the console sidewall and the padded part of the dashboard, to widen the gap. Push firmly forward on the right side of the ProClip so the angled right edge flexes forward and hooks into the gap next to the gap opener. Remove the gap opener.

4. The ProClip is in place.