

## Manual, Assembly instruction: Brodit 855242

Center mount



**Please read all of the instructions and look at the pictures before installing the ProClip.**

**1.** Press the thin end of the enclosed gap opener into the gap between the upper frame surrounding the information display and the inside part of the bottom of the center air vent to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip.

**2.** Press the angled bottom edge of the ProClip into the gap next to the gap opener. It is sometimes easier to start with a corner of the angled edge. Remove the gap opener.

**3.** Press the upper part of the ProClip downward and hook the upper notched edge of the ProClip under the upper center frame.

**4.** The ProClip is in place.