

Manual, Assembly instruction: Brodit 855243

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Open the storage compartment lid on top of the dashboard. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Hook the lower angled edge of the ProClip around the edge of the frame surrounding the information display.
2. Press the angled edge all the way in to the gap so the adhesive tape attaches properly.
3. Flex the upper edge of the ProClip forward/upward and hook the angled upper edge around the edge of the storage compartment.
4. The ProClip is in place.