

Manual, Assembly instruction: Brodit 855244

Center mount NOT for models with storage compartment with lid.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip. This ProClip can also be placed on the right side of the dashboard.

1. Insert the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the dashboard overhang and the frame surrounding the center control panel, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Insert the angled upper edge of the ProClip into the gap between the frame surrounding the storage compartment and the upper part of the dashboard.

2. Flex the ProClip downward + toward you so the angled upper edge hooks into place underneath the dashboard.

3. Pull the ProClip toward you, flexing it, so the angled lower edge goes into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).

4. The ProClip is in place.