

Manual, Assembly instruction: Brodit 855250

Angled mount, High

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Insert the left edge of the ProClip into the gap between the right side of the information display and the frame surrounding the airvent.
2. Insert the thin end of the enclosed gap opener into the gap between the frame surrounding the airvent and the padded top part of the dash, to widen the gap. Press forward on the right side of the ProClip until the angled right edge clips in behind the vent frame. Remove the gap opener.
3. Press the right side of the ProClip inward to make sure the adhesive tape attaches properly.
4. The ProClip is in place.