

Manual, Assembly instruction: Brodit 855253

Center mount



Please read all of the instructions and look at the pictures before installing the ProClip.

1.Press the thin end of the enclosed gap opener into the gap by the edge of the frame surrounding the air vents, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip.

2. Insert the angled lower edge of the ProClip into the gap next to the gap opener. Remove the gap opener.

3. Pull the top part of the ProClip upward and insert the angled upper edge of the ProClip into the gap below the display.

4. The ProClip is in place.