

Manual, Assembly instruction: Brodit 855255

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Press the lower angled edge of the ProClip into the gap dividing the central control panel and the lower edge of the dashboard.
2. Press the top part of the ProClip upward + forward and place it on the lower edge of the air vent.
3. Press firmly so the adhesive tape really fastens.
4. The ProClip is in place.