

Manual, Assembly instruction: Brodit 855257

Angled mount, High



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed gap opener into the gap between the frame surrounding the center information display/air vents and the padded part of the dash below the frame, to widen the gap. The photos show one gap opener, use both if the gap is tight. Remove the adhesive tape cover on the ProClip.

2. Hook the angled upper edge of the ProClip over the top of the frame surrounding the center information display/air vents.

3. Pull the lower part of the ProClip downward, and insert the lower angled edge into the gap next to the gap opener. Remove the gap opener.

4. The ProClip is in place.