

Manual, Assembly instruction: Brodit 855259

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip. This ProClip can also be placed on the left side, but will then block the ParkPilot + Park Assist-button.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap above the silver trimming, to widen the gap. Remove the adhesive tape covers on the ProClip.

2. Insert the angled lower edge of the ProClip into the gap below the panel housing the airbag and ParkPilot + Park Assist buttons.

3. Press the ProClip upward + forward and insert the angled upper edge into the gap next to the Gap Opener (Spaltöffner).

4. Remove the Gap Opener (Spaltöffner).