

## Manual, Assembly instruction: Brodit 855263

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**1.** Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed gap opener into the gap between the lower side of the frame surrounding the center vents and the top of the panel around the CD slot, to widen the gap. Remove the adhesive tape cover on the ProClip.

**2.** Insert the lower thin edge of the ProClip into the gap next to the gap opener. Remove the gap opener.

**3.** Insert the thin end of the gap opener into the gap between the upper frame surrounding the center vents and the padded part of the dash top, to widen the gap. Flex the upper part of the ProClip upward and insert the upper angled edge of the ProClip into the gap next to the gap opener. Remove the gap opener.

**4.** The ProClip is in place.