

Manual, Assembly instruction: Brodit 855264

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can also be placed on the right airvent.

- 1.** Press the thin end of the enclosed gap opener into the gap between the frame surrounding the airvent and the bottom of the vent, to widen the gap.
- 2.** Insert the thin lower edge of the ProClip into the gap next to the gap opener. Remove the gap opener.
- 3.** Press the upper edge of the ProClip downward, flexing it. Hook the J-shaped upper edge of the ProClip under the upper frame of the airvent.
- 4.** The ProClip is in place.