

Manual, Assembly instruction: Brodit 855267

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. NOTE: It is very important to attach the ProClip in the exact same position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover. Press the angled edge on the left part of the ProClip into the gap between the air vent and the surrounding frame.

2. Adjust the height of the ProClip in order to match the right part with the shape of the silver frame. Flex the ProClip to the left and press the thin right angled edge into the gap behind the frame surrounding the air vent. If needed: Use the enclosed gap opener to widen the gap.

3. The ProClip should be attached in this position.

4. The ProClip is in place.