

Manual, Assembly instruction: Brodit 855268

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the climate control panel and the dashboard, to widen the gap. Remove the adhesive tape cover on the ProClip.

2. Press the angled lower edge of the ProClip into the gap next to the gap opener. Press the lower part upward until it goes all the way into the gap. Remove the gap opener.

3. Press the gap opener into the gap between the panel surrounding the display and the frame surrounding the air vent. Pull the upper part of the ProClip upwards and hook the angled edge into the gap next to the gap opener. Press downwards on top of the ProClip so the angled edge goes all the way into the gap and the adhesive tape attaches properly. Pull out the gap opener.

4. The ProClip is in place.