

Manual, Assembly instruction: Brodit 855269

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled lower edge of the ProClip into the gap where the center console meets the dashboard. Flip/Rotate the ProClip upward/forward so the angled edge hooks behind the center console frame.

2. Press the upper part of the ProClip downward, flexing it, and insert the the upper angled edge into the gap behind the decorative panel.

3. The ProClip is in place.

4. The ProClip is in place.