

Manual, Assembly instruction: Brodit 855270

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the two dashboard sections, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.
2. Place/hook the angled edge on the lower part of the ProClip around the instrument panel frame edge.
3. Push forward on the top part of the gap opener to widen the gap further. Press firmly forward on the upper part of the ProClip so the angled edge goes into the gap next to the gap opener. Press until you see or hear/feel it click into place. Pull out the gap opener.
4. ProClip is in place.