

Manual, Assembly instruction: Brodit 855271

Angled mount



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Press the grooved edge on the lower part of the ProClip into the lower part of the air vent.

2. Press the upper part of the ProClip downward and forward, flexing it, and insert the angled upper edge into the gap between the dashboard overhang and the frame surrounding the air vent. Press forward on the ProClip so the angled edge goes all the way into the gap and the top part rests on the dashboard.

3. The ProClip is in place.

4. The ProClip is in place.