

Manual, Assembly instruction: Brodit 855275

Angled mount, Low



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the center console sidewall, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener.

2. Flip the upper part of the ProClip rightwards and hook the angled edge over the center console.

3. Press downward on the right side of the ProClip so the angled edge hooks into place properly and the adhesive tape attaches. Pull out the gap opener.

4. The ProClip is in place.