

Manual, Assembly instruction: Brodit 855280

Center mount, Low

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the curved edge on the right part of the ProClip into the gap between the frame surrounding the control panel and the frame surrounding the air vent. Flip the ProClip leftwards + forwards so the curved right edge hooks behind the frame surrounding the control panel.
3. Press forward on the left side of the ProClip so the angled edge hooks into the gap below the Gap Opener (Spaltöffner). Press until you hear + feel it snaps into place. Pull out the Gap Opener (Spaltöffner).
4. The ProClip is in place.