

Manual, Assembly instruction: Brodit 855281

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed anywhere within the width of the air vents.

1. Press the thin end of the enclosed gap opener into the gap between the panel and the trim, to widen the gap. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press forward on the panel to the right of the ProClip, in the same time press the gap opener into the gap between the panel and the dashboard.

3. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press downward on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.