

Manual, Assembly instruction: Brodit 855285

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the upper and the lower section of the dashboard.
2. Press the upper part of the ProClip upward/forward so the lower angled edge hooks behind the lower section of the dashboard.
3. Hook the upper part of the ProClip over the air vent frame so the upper edge is placed in the lower part of the air vent. Press downward on top of the ProClip so the adhesive tape attaches properly.
4. The ProClip is in place.