

Manual, Assembly instruction: Brodit 855286

Center mount



Please read all of the instructions and look at the pictures before installing the ProClip. This ProClip can be placed also on the right side of the dash.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Place the angled upper part of the ProClip onto the lower edge of the air vent.

2. Pull the lower part of the ProClip downward, so the angled lower edge hooks around the edge of the dashboard trim.

3. Press the lower part of the ProClip upward so the angled edge goes all the way into the gap.

4. The ProClip is in place.