

Manual, Assembly instruction: Brodit 855288

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
2. Press forward on the lower part of the ProClip so the angled edge hooks into the gap between the dashboard and the center console.
3. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.