

Manual, Assembly instruction: Brodit 855290

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the left part of the ProClip into the gap between the panel surrounding the parking brake and the center console frame.
2. Press downward on the right part of the ProClip so the angled edge hooks under the center console.
3. Press downward on the right part of the ProClip so the angled edge hooks properly in place under the center console.
4. The ProClip is in place.