

## Manual, Assembly instruction: Brodit 855292

Center mount



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Place the ProClip in the same height as shown in the pictures. Press the grooved edge on the right part of the ProClip into the gap between the frame surrounding the air vent and the frame surrounding the control panel.
2. Press forward on the right side of the ProClip until you hear/feel it snaps into place in the gap.
3. Press the grooved edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the dashboard overhang. Press forward on the upper part of the ProClip until you hear/feel it snaps into place in the gap.
4. The ProClip is in place.