

Manual, Assembly instruction: Brodit 855293

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Attach the angled left edge of the ProClip around the inside of the center console.
2. Press the right side of the ProClip forward until the angled right edge hooks behind the center console.
3. Make sure that the angled edge goes all the way around the edge.
4. The ProClip is in place.