

Manual, Assembly instruction: Brodit 855299

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place the ProClip in the exact same position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the dashboard and the center console.

2. Press the thin end of the enclosed gap opener into the gap on top of the dashboard, to widen the gap. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press downward on the ProClip so all the angled edge goes into the gap. Pull out the gap opener.

3. This ProClip can also be placed on the right side of the center console, in the exact same position as shown in the picture.

4. The ProClip is in place.