

Manual, Assembly instruction: Brodit 855300

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Use your thumb and gently press upward on the upper part of the air vent, to widen the gap slightly.

2. Press the angled edge on the upper part of the ProClip into the gap in the upper part of the air vent. Press the upper part of the ProClip upward so the angled edge goes all the way into the gap and the adhesive tape attaches.

3. Press the lower part of the ProClip upward/forward and hook the angled edge over the frame surrounding the air vent.

4. This ProClip can also be attached over the right air vent. The ProClip is in place.