

Manual, Assembly instruction: Brodit 855301

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Insert the grooved left side of the ProClip into the left inside of the airvent.
2. Make sure that the edge of the airvent goes properly into the grooved side of the ProClip.
3. Press the right side of the ProClip into the right side of the airvent. Press until you hear/feel that the ProClip snaps into place.
4. The ProClip is in place.