

Manual, Assembly instruction: Brodit 855302

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed gap opener into the gap in level with the top of the glove compartment, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Keep hold of the gap opener and at the same time insert the angled lower edge of the ProClip into the gap next to the gap opener. Remove the gap opener.

3. Insert the thin end of the gap opener into the gap above the air vent, to widen the gap. Pull the upper part of the ProClip upward/forward and insert the angled upper edge into the gap next to the gap opener. Remove the gap opener.

4. The ProClip is in place.