

Manual, Assembly instruction: Brodit 855306

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the air vent edge and the padded part of the dashboard, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the grooved edge on the lower part of the ProClip into the gap next the gap opener. Press until you see or hear/feel it click into place. Pull out the gap opener.

2. Press the gap opener into the gap between the air vent edge and the padded part of the dashboard. Press forward on the upper part of the ProClip so the angled edge goes into the gap next the gap opener. Press down on top right side of the ProClip to make sure the angled edge is all the way into the gap. Pull out the gap opener.

3. Press the gap opener into the gap between the air vent edge and the padded part of the dashboard on the left side of the ProClip. Press forward and down on the upper part of the ProClip to make sure the angled edge goes all the way into the gap. Press until you see or hear/feel it click into place. Pull out the gap opener.

4. The ProClip is in place.